


At the first maintenance job


Engine M 100.980

V-belt	Deflection with 6 kp load
A	approx. 10
B	
C	
D	approx. 5
E	approx. 10




V-belts A and E


- Loosen counter nut (1) and fixing bolt (2)
- Adjust V-belt tension with the tensioning nut (3).
- Tighten fixing bolt and tensioning nut.




Double V-belt B

- Loosen fixing bolt (1) of the tensioner pulley (2) and adjust V-belts to the prescribed tension by repositioning tensioner pulley.
- Tighten fixing bolt.



**Double V-belt C**

- Loosen the two fixing bolts (1) and the four fixing bolts on the base of the air compressor (2) as well as the counter nut (3).
- Tension the V-belts with the adjusting screw (4).
- Tighten fixing bolts and counter nut.


**V-belt D**

- Loosen the four hex.-hd. bolts (1).
- Tension V-belt by turning the threaded boss (2) to the right. Turn the engine at intervals with the starter so that the V-belt can adjust to the moveable pulley.
- Tighten hex-hd. bolts.

At the first maintenance job


Engine M 100.981 / 983

V-belt	Deflection in mm with 6 kp load
A	
B	approx. 10
C	




V-belt A

- Loosen counternut (1) and fixing bolt (2).
- Adjust V-belt tension with tensioning nut (3).
- Tighten fixing bolt and counternut.




Double V-belt B

- Loosen fixing bolts (1) and the four fixing bolts (2) on the air compressor base, as well as the counternut (3).
- Tension V-belt with the adjustment screw (4).
- Tighten fixing bolts and counternut.




Double V-belt C

- Loosen fixing bolt (1) of the tensioner pulley (2).
- Adjust V-belt tension by repositioning tensioner pulley.
- Tighten fixing bolt.




Engine M 116, 117


At the first maintenance job




V-belt	Deflection in mm with 6 kp load
A	approx. 10
B	
C	
D	approx. 5

**V-Belt A, Compressor Air Suspension**


- Loosen the four fixing bolts (1) and the clamp for the air pipe bracket.
- Push a screwdriver or punch through the hole in plate (2), rest on bolt (3) and lever air compressor outwards.
- Tighten fixing bolts (1) and air pipe clamp.

**V-Belt A, Air Pump USA 74**

- Loosen clamping screws 1 and 2, as well as fastening bolts 3.
- Push air pump outwards until V-belt is tensioned.
- Tighten clamping screws and fastening bolts.


**Double V-belt B**

- Loosen fixing bolts (1, 2 and 4).
- Only loosen fixing bolt (3, pivot) slightly.
- Adjust tension of V-belt by moving high pressure pump outwards.
- Tighten fixing bolts.


**Note**

If adjustments can still be made but the adjusting possibilities of fastening bolts (1) are exhausted, transfer fastening bolt (2) from tapped hole "a" to tapped hole "b".


When replacing V-belts, return fastening bolt (2) again to hole "a".

**V-belt C**

- Loosen counter nut (5) and fixing bolt (6).
- Tension V-belt with tensioning nut (7).
- Lock tensioning nut with the counter nut and tighten fixing bolt.


**V-belt D**

- Loosen fixing bolt (9) of the tensioner wheel (8).
- Adjust V-belt tension by moving tensioner wheel.
- Tighten fixing bolt.




M 114 115 130 180 **Alternator with Single Pulley**
OM 615 616

During first maintenance job



V-belt	Impression depth in mm at 6 kp load
A	approx. 10
B	
C	
D	approx. 5


1 Crankshaft	5 Tensioning pulley
2 Water pump	6 High-pressure oil pump
3 Alternator	7 Vacuum pump
4 Refrigerant compressor	



V-Belt A

Version up to August 73


- Loosen counter nut (1) and fastening bolt (2).
- Adjust V-belt tension with tensioning nut (3).
- Counterlock tensioning nut and tighten fastening bolt.



V-Belt A

Version as from August 73

- Loosen hex. nut (1) of tensioning screw (2) and fastening bolt (3).
- Adjust V-belt tension on hexagon of tensioning screw (2) and tighten hex. nut (1).
- Tighten fastening bolt (3).




V-Belt B


- Loosen fastening bolt (1).
- Tension V-belt by swivelling tensioning pulley (2).
- Tighten fastening bolt.

V-Belt C



- Loosen fastening bolts (1 and 2).
- Tension V-belt by swivelling vacuum pump.
- Tighten fastening bolts again.


**V-Belt D**

- Loosen fastening bolts on face of high-pressure pump (1) and at the rear (2).




- On engines M 115, OM 615, 616, force high-pressure pump outwards with lever and tighten fastening bolts again.



**Gasoline engine M 115****Diesel engine OM 615, 616**



- On engines M 114, 130, 180 loosen counternut (3) and adjust V-belt tension with the adjusting nut (4).
- Tighten fixing bolts and counternut.



M 114 130 180 Alternator with Double Pulley



- On vehicles with engines M 114, 130, 180 **and righthanddrive** the two fastening bolts of the hose clamps must also be loosened and retightened after tensioning.

During first maintenance job

V-belts	Impression depth in mm at 6 kp load
A	approx. 10
B	
C	approx. 5

Double V-belt A

- Loosen fixing bolt (1).
- Lever generator outwards. (With air conditioning system, from below.)
- Tighten fixing bolt (1) and retighten fixing bolts (2) and (3).

V-belts B and C, adjust as described under alternator with single pulley.

At the first maintenance job

Engine M 110


Special tools

Pin spanner insert SW 8 mm, 105 mm long, 1/2" square

000 589 34 07 00


V-belts	Impression depth in mm at 6 kp load
A	approx. 10
B	
C	
D	approx. 5

- | | |
|--------------------------|--------------------------|
| 1 Crankshaft | 5 Tensioning pulley |
| 2 Water pump | 6 Air pump |
| 3 Alternator | 7 High-pressure oil pump |
| 4 Refrigerant compressor | |




V-belt A


- Loosen hex. nut (2).
- Adjust tension on 6 mm square (1) or on hexagon SW 17 of tensioning screw (3).
- Tighten hex. nut (2).



V-belt B 1st version

- Introduce suitable tool of approx. 8 mm dia. into recess of bracket (1).
- Loosen fastening screw (2).
- Adjust V-belt tension by swiveling bracket (1).
- Tighten fastening screw (2).






V-Belt B 2nd Version

- Loosen expanding screw (1).
- Adjust V-belt tension with adjusting screw (2).
- Tighten expanding screw (1) to 16 Nm (1.6 kpm).


Note

A number of vehicles have been delivered with a counter nut on adjusting screw (2). For this version, the V-belt tension is adjusted at counter nut. But it will be of advantage to exchange adjusting screw M 6 x 90 for screw M 6 x 75 and to mount without counter nut.



V-Belt C USA Model Year 74

- Loosen fastening bolt (1).
- Adjust V-belt tension by swivelling air pump outwards.
- Tighten fastening bolt (1).



V-Belt D

- Loosen hex. socket screw (2) with socket wrench insert SW 8 x 105.
- Loosen hex. socket screw (1) and hex. screw (3).
- Adjust tension on hexagon SW 17 of toothed washer (4).
- Tighten hex. socket screws (1 and 2).
- Tighten fastening bolt (3).

V-Belt D USA Model Year 74

- Loosen fastening bolt (1).
- Adjust V-belt tension by swivelling high-pressure oil pump outwards.
- Tighten fastening bolt (1).

