




Mercedes-Benz  
service

# Mercedes-Benz CONTINUOUS INJECTION SYSTEM (CIS) Diagnosis & Adjustment — (1976-1979)



Education  
For  
Excellence

**Mercedes-Benz**  
**CONTINUOUS INJECTION SYSTEM (CIS)**  
**Diagnosis & Adjustment**  
**(1976-1979)**

**MERCEDES-BENZ OF NORTH AMERICA**  
**SERVICE TRAINING DEPARTMENT**


**Table of Contents**  
**C.I.S. TEST SEQUENCE**

<b>TEST</b>		<b>PAGE</b>
<b>TEST 1</b>	CHECK THROTTLE CONTROL LINKAGE (6 CYL.) .....	2
<b>TEST 1</b>	CHECK THROTTLE CONTROL LINKAGE (8 CYL.) .....	6
<b>TEST 2</b>	TESTING FUEL PUMP DELIVERY VOLUME .....	10
<b>TEST 3</b>	TESTING PRIMARY SYSTEM PRESSURE .....	15
<b>TEST 4</b>	STATIC PRESSURE TEST .....	21
<b>TEST 5</b>	INJECTION NOZZLE LEAK TEST (INSTALLED) .....	23
<b>TEST 6</b>	TESTING COLD-START VALVE SYSTEM .....	24
<b>TEST 7</b>	TESTING COLD CONTROL PRESSURE .....	27
<b>TEST 8</b>	TESTING OPERATION OF AUXILIARY AIR VALVE .....	30
<b>TEST 9</b>	TESTING WARM CONTROL PRESSURE .....	32
<b>TEST 10</b>	TESTING FULL LOAD VACUUM ENRICHMENT .....	35
<b>TEST 11</b>	TESTING IDLE SPEED AND C/O ADJUSTMENT .....	36
<b>TEST 12</b>	TESTING INJECTION NOZZLES (REMOVED) .....	42
<b>TEST 13</b>	TESTING FUEL DISTRIBUTOR .....	47


## C.I.S. PROBLEM DIAGNOSIS CHART

PROBLEM/COMPLAINT	TEST NUMBERS						
NO START	3	4	2				
HARD STARTING	3	4	6				
ROUGH IDLE	3	5	8	11	12	13	
HIGH IDLE	8						
STUMBLE ON ACCELERATION (WARM)	3	5	9	10	11		
STUMBLE ON ACCELERATION (COLD)	3	7	10				
ENGINE MISS	3	5	11	12	13		
LACK OF POWER	1	3	7	9	10	11	13
HIGH SPEED BREAK-UP	3	4	2				
ERRATIC TRANSMISSION SHIFTING	1						
POST-DETONATION (DIESELING)	3	5	11	12			

## CIS Injection System — 1976, 1977, 1978 Models



## CIS Injection System — 1979 Models



- 1 Mixture Regulator Assembly
- 2 Airflow Sensor
- 10 Idle Air Screw
- 20 Fuel Distributor
- 21 Primary System Pressure Regulator
- 30 Pressure Compensating Valve

- 55 Safety Switch
- 61 Idle Mixture Screw
- 70 Warm Up/Full Load Enrichment Compensator
- 80 Injection Nozzle
- 85 Fuel Accumulator
- 86 Fuel Filter


- 87 Fuel Pump
- 95 Suction Damper
- 96 Auxiliary Air Valve
- 98 Cold-Start Valve
- 99 Thermo Time Switch
- 105 Pressure Damper
- 110 Fuel Tank

## TEST 1

## CHECK THROTTLE CONTROL LINKAGE (6 CYL.)


**DESCRIPTION** — Characterized by problems in controlling throttle opening and transmission shifting.

**PURPOSE** — To check linkage operation and adjustment.




1.1

**OPERATE** linkage. It should move freely.




1.2

**CHECK** idle stop. The throttle valve lever should rest against it (arrow).




1.3  
**CHECK** roller (3). It should rest tension free at the end of the slot of the gate lever (4).



1.4  
**DEPRESS** accelerator pedal from inside car to touch kick down button.

The throttle valve lever should touch the full throttle stop (arrow).



1.5  
**DISCONNECT** control pressure rod (11) and push toward rear.

It should reconnect to the ball joint tension free.




IF CORRECT, proceed to next test as specified in Problem Diagnosis Chart.



IF NOT CORRECT, ADJUST LINKAGE (NEXT PAGE)

## CORRECTING THROTTLE CONTROL LINKAGE (6 CYL.)



1.6


Throttle valve lever does not rest against idle stop:

**MEASURE** and correct length of control rods 2-5-10:

ROD 2 — 343 mm (13½") center to center of ball sockets.

ROD 5 — 186 mm (7-5/16") center of ball socket to center of damping ring.

ROD 10 — 306 mm (12") center to center of ball sockets.




1.7

The roller does not rest at the end of the slot tension free:


**ADJUST** control rod (2) as necessary.





1.8  
The throttle valve lever does not touch the full throttle stop:

- a. **ADJUST** control linkage travel with hex nut (arrow).
- b. **MEASURE** and correct length of control rod (5). See step 1.6.



1.9  
The control pressure rod (11) does not fit the ball joint tension free:

**ADJUST** length of rod at ball joint (arrow) to fit.




IF CORRECT, proceed to next test as specified in Problem Diagnosis Chart.

## TEST 1


# CHECK THROTTLE CONTROL LINKAGE (8 CYL.)

**DESCRIPTION** — Characterized by problems in controlling throttle opening and transmission shifting.

**PURPOSE** — To check linkage operation and adjustment.




1.1  
**OPERATE** linkage. It should move freely.



1.2  
**DISCONNECT** rod (1) and check basic linkage adjustment.

a. The throttle valve lever should rest against the idle stop.


b. Rod (1) should then reconnect tension free.



1.3

**DEPRESS** accelerator pedal from inside car to **TOUCH** kick-down button.

The throttle valve lever should touch the full throttle stop on the throttle valve housing.



1.4

**COMPRESS** — adjusting clip (7) and push control pressure rod fully toward the rear. (Do not force beyond stop).

Control pressure rod is thereby adjusted.




IF CORRECT, proceed to next test as specified in Problem Diagnosis Chart.



IF NOT CORRECT, ADJUST LINKAGE (NEXT PAGE)


## CORRECTING THROTTLE CONTROL LINKAGE (8 CYL.)



1.5

Rod (1) does not reconnect tension free.


**ADJUST** rod (2) so that roller (3) rests tension free in slot of gate lever (4).



1.6

The throttle valve lever does not touch the full throttle stop at the same time the kick down button is touched:

**ADJUST** linkage at nut (arrow).




1.7


**RECHECK** that idle stop and full throttle stop are contacted.

**IF NOT CORRECT:** CHECK length of control rods:

- a. Rod (1) from throttle valve lever to bell crank = 104mm (4 $\frac{1}{8}$ "") from center socket to center ball socket.



b. Rod (arrow) from accelerator pedal to bell crank lever = 122mm (4-13/16") from center ball socket to center ball socket.



1.8  
**RECHECK** that idle stop and full throttle stop are contacted.

**IF NOT CORRECT:** ADJUST accelerator pedal from inside vehicle:

LOOSEN screw (arrow) and pull pedal upwards slightly.




IF CORRECT, proceed to next test as specified in Problem Diagnosis Chart.

## TEST 2

## TESTING FUEL PUMP DELIVERY VOLUME

**DESCRIPTION** — Characterized by high speed fuel starvation. If totally restricted could cause a no-start situation.


**PURPOSE** — Tests condition of fuel pump, fuel filter, and fuel accumulator.



**NOTE:** The volume test does not test for an inoperative fuel tank venting system which would also cause a fuel starvation problem.

2.1

**REMOVE** fuel tank cap to release pressure in fuel tank.




2.2

**DISCONNECT** fuel return hose on fuel distributor.




2.3

**CONNECT** fuel line (901 589 00 21 00) to fuel distributor.




2.4  
**PLACE** fuel line into measuring container.



2.5  
**DISCONNECT** plug (arrow) on enrichment compensator.

**NOTE:** Avoid heating up compensator until cold control pressure value is checked.



2.6  
**TURN ON** ignition. Then **DISCONNECT** fuel pump safety switch to run fuel pump.



**VALUE** = 1 liter in 30 seconds  
(min.) with fuel tank at least half  
full and 11.5 volts min. at fuel  
pump.



2.7  
**READ** fuel pump delivery volume.




IF CORRECT, proceed to  
next test as specified in  
Problem Diagnosis Chart.



IF NOT CORRECT,  
CONTINUE FURTHER  
TESTING




Fuel pump delivery volume is not correct:  
ADDITIONAL TESTING — FUEL PUMP DELIVERY VOLUME



2.8  
**CHECK** for restriction in screw fitting  
strainer at fuel distributor.



2.9  
**CHECK** fuel filter for restriction.



2.10  
**TEST** voltage at fuel pump terminal B+.

////////////////////////////////////  
**VALUE** = min. 11.5 volts.  
 //////////////////////////////////////



IF CORRECT:  
 REPLACE fuel pump.



- IF NOT CORRECT:
- a. CHECK battery.
  - b. CHECK for resistance in electrical circuit to fuel pump (see E.T.M.).
  - c. CHECK for restriction in fuel circuit between pump and fuel pressure regulator.
  - d. REPLACE fuel pump.

////////////////////////////////////  
**VALUE** = 1 liter in 30 seconds.  
 //////////////////////////////////////

2.11  
**REPEAT** fuel pump volume test.



IF CORRECT, proceed to next test as specified in Problem Diagnostic Chart


## TEST 3

## TESTING PRIMARY SYSTEM PRESSURE

**DESCRIPTION** — Characterized by a rough idle, hard starting (cold), & stumble on acceleration.

**PURPOSE** — Tests adjustment or condition of pressure regulator and condition of the fuel return circuit.


**NOTE:** The pressure gauge hook-up remains the same for all pressure tests. To prevent damage to seals, always keep gauge valves open.



107-10591


Part # 100 689 13 21 00  
GAUGE

C.I.S. PRESSURE GAUGE IN BAR



Part # 900 589 13 21 00  
GAUGE


C.I.S. PRESSURE GAUGE IN P.S.I.



3.1  
**CHECK** all fuel connections for external leaks.




3.2  
**REMOVE** fuel tank cap.



3.3  
**DISCONNECT** plug (arrow) on enrichment compensator.


**NOTE:** Avoid heating up compensator until cold control pressure value is checked.



3.4


**INSTALL** gauge into control pressure circuit as follows:

Remove control pressure line at fuel distributor and connect gauge in between using adaptor fitting if necessary.



3.5

**CLOSE VALVE** on down-stream side of pressure gauge.



3.6  
**TURN ON** ignition and disconnect fuel pump safety switch to run fuel pump.

////////////////////  
**VALUE** = 5.2-5.8 bar (76-84 psi).  
////////////////////

3.7  
**READ** primary system pressure.




IF CORRECT, proceed to next test as specified in Problem Diagnosis Chart.



IF NOT CORRECT, remove pressure regulator and attempt adjustment by changing adjusting shim

# CORRECTING PRIMARY SYSTEM PRESSURE



3.8  
**REMOVE** pressure regulator and attempt adjustment by changing adjusting shim (4).

**NOTE:** 0.1mm = 0.1 bar change  
 (.004") = (1.5 psi)

////////////////////////////////////  
 VALUE = 5.2-5.8 bar (76-84 psi).  
 //////////////////////////////////////

3.9  
**REPEAT** Test.



IF CORRECT, proceed to next test as specified in Problem Diagnosis Chart.



IF NOT CORRECT, if primary system pressure can not be corrected by replacing adjustment shims:

**RECONDITION PRIMARY SYSTEM PRESSURE REGULATOR**

SERVICE MICROFICHE GROUP 07.3. JOB # 210

////////////////////////////////////  
 VALUE = 5.2-5.8 bar (75-84 psi)  
 //////////////////////////////////////

3.10  
**CHECK** primary system pressure:



IF CORRECT, proceed to next test as specified in Problem Diagnosis Chart.



IF NOT CORRECT, REMOVE Primary system pressure regulator again. ADJUST by adding or removing adjusting shims (4).

**NOTE:** 0.1mm = 0.1 bar change  
 (.004") = (1.5 psi)

////////////////////////////////////  
 VALUE = 5.2-5.8 bar (76-84 psi).  
 //////////////////////////////////////

3.11  
**REPEAT** Test.




IF CORRECT, proceed to next test as specified in Problem Diagnosis Chart.



IF NOT CORRECT, IF PRESSURE REMAINS HIGH, CONTINUE (NEXT PAGE)



3.12  
**DISCONNECT** fuel return line at fuel distributor, attach fuel volume test hose, and place end in suitable container.



3.13  
Run fuel pump (page 11) and **OBSERVE** pressure gauge.

////////////////////////////////////  
**RESULT:** The pressure should now be lower than previous readings.  
////////////////////////////////////

////////////////////////////////////  
**NOTE:** If pressure is now lower than previous readings there is a restriction in the fuel return circuit. Find and repair cause of restriction.  
////////////////////////////////////

////////////////////////////////////  
**VALUE = 5.2-5.8 bar (76-84 psi).**  
////////////////////////////////////

3.14  
**REPEAT** primary system pressure test.



IF CORRECT, proceed to next test as specified in Problem Diagnosis Chart.



IF NOT CORRECT, REMOVE PRIMARY SYSTEM PRESSURE REGULATOR AGAIN. ADJUST BY ADDING OR REMOVING ADJUSTING SHIMS.




## TEST 4

## STATIC PRESSURE TEST


**DESCRIPTION** — Characterized by hard starting.

**PURPOSE** — Tests for internal system leakage that could be caused by: pressure regulator, cold-start valve, fuel pump non-return valve, leaking diaphragm in accumulator, pressure compensating valve, flow control valve, or leakage around control plunger or O-ring on metering sleeve in fuel distributor.



**NOTE:** See Test 3 for connecting gauge.

4.1  
**OPEN** valve(s) on gauge.



4.2  
**TURN ON** ignition and run fuel pump for 30 seconds to fill accumulator.



**VALUE** = approx. 2.8 bar (41 psi)  
should hold steady.

After 30 minutes, the pressure  
should still be approximately  
2.5 bar (36 psi).



4.3  
**TURN OFF** ignition and read static pressure.




IF CORRECT, proceed to  
next test as specified in  
Problem Diagnosis Chart.




IF NOT CORRECT,  
check the following  
to locate the  
leakage:  
(NEXT PAGE)


## ADDITIONAL CHECKS — STATIC PRESSURE LOSS




4.4  
**CHECK** primary system pressure regulator and flow control valve.



4.5  
**CHECK** cold-start valve.




4.6  
**CHECK** fuel pump non-return valve.



4.7  
**CHECK** accumulator for leaking diaphragm.



4.8  
**CHECK** pressure compensating valve.



4.9  
**CHECK** fuel distributor for internal leakage around control plunger or O-ring of metering sleeve.




IF CORRECT, proceed to next test as specified in Problem Diagnosis Chart.

## TEST 5

## INJECTION NOZZLE LEAK TEST (INSTALLED)


**DESCRIPTION** — Characterized by an engine miss after starting, stumble on acceleration, and post detonation (dieseling) on shut off.

**PURPOSE** — To test for leaking injection nozzles.



**CAUTION:** Ignition must be **OFF!**

5.1  
**OPEN** valve(s) on gauge.



5.2  
**PRESS** sensor plate down slowly.

**RESULT:** the fuel pressure should move momentarily, then return and hold steady.

5.3  
**OBSERVE** gauge.



IF CORRECT, proceed to next test as specified in Problem Diagnosis Chart.



IF NOT CORRECT, go to "TEST 12".  
(PAGE 42)

## TEST 6


## TESTING COLD-START VALVE SYSTEM

**DESCRIPTION** — Characterized by an engine that is hard starting — hot or cold.

**PURPOSE** — Test that cold-start valve opens during cranking, does not leak after closing, and does not open on a hot engine.

### A — TEST COLD-START VALVE

6 CYLINDER



8 CYLINDER



6A.1

**REMOVE** cold-start valve leaving it connected to fuel line and wiring harness and place valve in container.

6 CYLINDER



8 CYLINDER




6A.2


**DISCONNECT** plug on thermo time switch.

## B — TEST THERMO TIME SWITCH

**NOTE:** If the complaint is a hard starting engine, the thermo time switch should be checked in a hot state then removed from the engine and checked in a cold state.



6B.1  
**DISCONNECT** plug on thermo time switch (99).



6B.2  
**TEST** resistance at the "G" and "W" terminal pins of the thermo time switch.

////////////////////  
**COLD STATE**

**VALUES BELOW** 15°C/59°F  
coolant temperature:

G to ground = approx. 50 ohms.

W to ground = approx. 0 ohms  
(contacts in switch closed).

////////////////////



////////////////////  
**HOT STATE**

**VALUES ABOVE** 15°C/59°F  
coolant temperature:

G to ground = approx. 60 ohms.

W to ground = approx. 270 ohms  
(contacts in switch open).

////////////////////



IF CORRECT, proceed to  
next test as specified in  
Problem Diagnosis Chart.



IF NOT CORRECT, replace the  
thermo-time switch.


## TEST 7

## TESTING COLD CONTROL PRESSURE

**DESCRIPTION** — Characterized by poor acceleration, stumble or lack of power when cold.


**PURPOSE** — To check enrichment compensator for cold operation.

**NOTE:** The engine *must be cold* before this test can be conducted. This means that the vehicle must stand at ambient temperature *at least six hours* and may not be started before performing this test.




7.1

**DETERMINE** temperature of enrichment compensator assembly.



7.2

1. **OPEN** Valve(s) on pressure gauge.
2. Unplug compensator to prevent electric heat coils from operating.



7.3

**START** the engine and **IMMEDIATELY** ...

VALUE: Dependant on temperature of compensator assembly, pressure should be as shown on applicable chart.

7.4  
READ the pressure gauge.

NOTE: Do not warm engine up during this test as operation of auxiliary air valve is performed during the warm-up phase.

## ENGINE M100

### ENGINE M100 — 1977/78 ONLY

F° = psi	C° = bar
32 = 7-13	0 = 0.5-0.9
41 = 7-13	5 = 0.5-0.9
50 = 10-16	10 = 0.7-1.1
59 = 13-19	15 = 0.9-1.3
68 = 16-22	20 = 1.1-1.5
77 = 19-25	25 = 1.3-1.7
86 = 22-28	30 = 1.5-1.9
95 = 25-31	35 = 1.7-2.1
104 = 28-33	40 = 1.9-2.3

### ENGINE M100 — 1979

F° = psi	C° = bar
32 = 9-15	0 = 0.6-1.0
41 = 12-18	5 = 0.8-1.2
50 = 15-20	10 = 1.0-1.4
59 = 18-23	15 = 1.2-1.6
68 = 20-25	20 = 1.4-1.8
77 = 23-29	25 = 1.6-2.0
86 = 25-32	30 = 1.8-2.2
95 = 29-35	35 = 2.0-2.4
104 = 32-37	40 = 2.2-2.6

## ENGINE M110

### ENGINE M110 — 1976-1979

except hi-altitude version

F° = psi	C° = bar
32 = 7-13	0 = 0.5-0.9
41 = 9-15	5 = 0.6-1.0
50 = 12-18	10 = 0.8-1.2
59 = 15-20	15 = 1.0-1.4
68 = 18-23	20 = 1.2-1.6
77 = 20-25	25 = 1.4-1.8
86 = 23-29	30 = 1.6-2.0
95 = 25-32	35 = 1.8-2.2
104 = 29-35	40 = 2.0-2.4

### ENGINE M110 — 1976-1979

high altitude version only

F° = psi	C° = bar
32 = 9-15	0 = 0.6-1.0
41 = 12-18	5 = 0.8-1.2
50 = 15-20	10 = 1.0-1.4
59 = 18-23	15 = 1.2-1.6
68 = 20-25	20 = 1.4-1.8
77 = 23-29	25 = 1.6-2.0
86 = 25-32	30 = 1.8-2.2
95 = 29-35	35 = 2.0-2.4
104 = 32-37	40 = 2.2-2.6

## ENGINE M117

### ENGINE M117 — 1976/77/78

F° = psi	C° = bar
32 = 9-15	0 = 0.6-1.0
41 = 12-18	5 = 0.8-1.2
50 = 15-20	10 = 1.0-1.4
59 = 18-23	15 = 1.2-1.6
68 = 20-25	20 = 1.4-1.8
77 = 23-29	25 = 1.6-2.0
86 = 25-32	30 = 1.8-2.2
95 = 29-35	35 = 2.0-2.4
104 = 32-37	40 = 2.2-2.6

### ENGINE M117 — 1979


F° = psi	C° = bar
32 = 12-18	0 = 0.8-1.2
41 = 15-20	5 = 1.0-1.4
50 = 18-23	10 = 1.2-1.6
59 = 20-25	15 = 1.4-1.8
68 = 23-29	20 = 1.6-2.0
77 = 25-32	25 = 1.8-2.2
86 = 29-35	30 = 2.0-2.4
95 = 32-37	35 = 2.2-2.6
104 = 35-42	40 = 2.4-2.8



IF CORRECT, proceed to next test as specified in Problem Diagnosis Chart.



IF NOT CORRECT, Continue Further Testing (NEXT PAGE)



Cold control pressure is **NOT CORRECT**:

7.5  
**REPLACE** enrichment compensator temporarily.

or adjust by driving 9mm stud (recessed) next to plug-in down to reduce p.s.i. (richer) with "Key on" or motor running

////////////////////  
**VALUE:** See applicable chart on preceeding page.  
////////////////////

7.6  
**REPEAT** cold control pressure test.



IF CORRECT, complete installation of new enrichment compensator and proceed to next test as specified in Problem Diagnosis Chart.



IF NOT CORRECT, Check for a restriction in circuits to and from enrichment compensator.




## TEST 8


# TESTING OPERATION OF AUXILIARY AIR VALVE

**DESCRIPTION** — Characterized by engine running rough and dying at cold idle (if stuck in closed position) or engine idles high when warm (if stuck in open position).

**PURPOSE** — Check opening and closing of the auxiliary air valve.



8.1  
**(RECONNECT** plug of enrichment compensator, if disconnected.)



8.2  
**CONNECT** tachometer.

////////////////////  
**VALUES:** Cold engine = 800 - 1000 rpm

Max. increase = 1200 - 1300 rpm

**NORMAL IDLE SPEED RETURNS AT 70°C/158°F**


8.3  
**RUN** engine and read tachometer.



IF CORRECT,  
CONTINUE



IF NOT CORRECT, REPLACE  
AUXILIARY AIR VALVE



8.4  
**PINCH** air hose from air valve shut after engine is fully warm.

**RESULT:** Idle speed should not change noticeably.




IF CORRECT, proceed to next test as specified in Problem Diagnosis Chart.




IF NOT CORRECT, REPLACE AUXILIARY AIR VALVE.

### LOCATION OF AUXILIARY AIR VALVE (96)



6 CYLINDER




8 CYLINDER

## TEST 9

# TESTING WARM CONTROL PRESSURE

**DESCRIPTION** — Characterized by poor acceleration, or lack of power when engine temperature is warm.

**PURPOSE** — To check enrichment compensator for warm operation.



9.1  
**OPEN** valve(s) on pressure gauge.

AND

9.2  
**IDLE** engine at operating temperature.

VALUES with compensator fully warm:\*

### ENGINE M100

FEDERAL AND CALIFORNIA  
3.4-3.8 bar (49-55 psi)  
Federal high altitude  
3.6-4.0 bar (52-58 psi)

### ENGINE M110

FEDERAL  
3.4-3.8 bar (49-55 psi)  
CALIFORNIA  
3.0-3.4 bar (44-49 psi)  
Federal high altitude  
3.6-4.0 bar (52-58 psi)

### ENGINE M117

FEDERAL AND CALIFORNIA  
3.4-3.8 bar (49-55 psi)  
Federal high altitude  
3.6-4.0 bar (52-58 psi)

### NOTE:

Pressure values given are obtained at an engine vacuum of:

400 mm Hg. (16 in. Hg.)

If engine vacuum is:

300 mm Hg. *subtract* 0.1 bar  
(12 in. Hg. *subtract* 1.5 psi)

If engine vacuum is:

500 mm Hg. *add* 0.1 bar  
(19.5 in. Hg. *add* 1.5 psi)




IF CORRECT, proceed to next test as specified in Problem Diagnosis Chart.



IF NOT CORRECT, CONTINUE FURTHER TESTING

# CORRECTING WARM CONTROL PRESSURE



If the warm control pressure is  
**NOT CORRECT:**

## A — TEST INTAKE MANIFOLD VACUUM.

9.3  
**CONNECT** vacuum gauge into vacuum  
hose to enrichment compensator with  
T-fitting.



**VALUES** = approx. 350-450 mm  
Hg. (14-18 in Hg.)

**NOTE:** Control pressure values  
given are obtained at a vacuum  
of 400 mm Hg. (16 in. Hg.)



9.4  
**RUN** engine at idle:




IF CORRECT,  
CONTINUE FURTHER TESTING  
(NEXT PAGE)



IF NOT CORRECT (low vacuum)  
determine cause and repair as  
necessary.

POSSIBLE CAUSES of low vacuum:

- a. Engine intake system leaking air.
- b. Exhaust system restricted.  
Check for plugged-catalytic  
converter.
- c. Ignition timing incorrect.
- d. Burned or tight valves.
- e. Enrichment compensator vacuum  
diaphragm leaking.



~~~~~  
VALUE = Approx. 13.5 volts.  
~~~~~

If the warm control pressure temperature is **NOT CORRECT**:

**B — TEST VOLTAGE AT THE ENRICHMENT COMPENSATOR**

9.5  
RUN engine AND . . .

9.6  
**DISCONNECT** plug on enrichment compensator.


9.7  
**TEST** voltage at plug.



IF CORRECT, CONTINUE  
FURTHER TESTING.  
(BELOW)



IF NOT CORRECT,  
CHECK ELECTRICAL CIRCUIT



~~~~~  
VALUE = Approx. 30 ohms.  
~~~~~

If the warm control pressure is **NOT CORRECT**:

**C — TEST HEATING COIL**

9.8  
**CONNECT** ohm meter to the two pins of the enrichment compensator.

**NOTE:** Do not use a high scale ohm meter to check. Use 100 ohm max. reading scale.

9.9  
**READ** ohm meter.

**NOTE:** A defective heating coil will be indicated by a zero or infinity reading (0 or  $\infty$ ).




IF CORRECT, proceed to  
next test as specified in  
Problem Diagnosis Chart.



IF NOT CORRECT,  
REPLACE ENRICHMENT  
COMPENSATOR


**DESCRIPTION** — Characterized by a stumble on acceleration with a warm or cold engine.  
**PURPOSE** — To check the enrichment compensator for full load operation.



10.1  
**OPEN** valve(s) on pressure gauge.

AND . . .

10.2  
**RUN** engine until warm-up cycle of enrichment compensator is completed.



10.3  
**DISCONNECT** vacuum line of enrichment compensator and plug resulting vacuum leak.

**NOTE:** The larger hose is always the vacuum line.

////////////////////////////////////  
**VALUES:**

**ENGINE M100**

(1976-1978)  
 3.0-3.4 bar (43-49 psi)  
 (1979)  
 2.8-3.2 bar (41-46 psi)  
 Federal High Altitude  
 3.2-3.6 bar (46-52 psi)

**ENGINE M110**

(1976-1979)  
 2.8-3.2 bar (41-46 psi)  
 Federal High Altitude  
 3.0-3.4 bar (43-49 psi)

**ENGINE M117**

(1976-1979)  
 3.0-3.4 bar (43-49 psi)  
 Federal High Altitude  
 3.2-3.6 bar (46-52 psi)

////////////////////////////////////




IF CORRECT, proceed to next test as specified in Problem Diagnosis Chart.



IF NOT CORRECT, replace warm-up/full load enrichment compensator.


**DESCRIPTION** — Characterized by engine stumbling, poor fuel economy, and rough idle. Will cause high C/O emission levels and possible burning of the catalyst.

**NOTE:** If an oil change is to be included, do before checking C/O. Also, check idle speed, ignition timing, and plug gap before adjusting C/O.



11.1

**TURN OFF** the air conditioning system.



11.2

**REMOVE** the air cleaner.



11.3

**CHECK** to see if the bowden cable for the cruise control rests tension free against the throttle lever (arrow). If necessary, adjust bowden cable at the adjusting nut (1).





11.4

**RUN** engine until an oil temperature of 140-176°F (60-80°C) is reached.

**NOTE: DO NOT ADJUST** on an over hot engine.

6 CYLINDER

8 CYLINDER




11.5

**ADJUST** to correct idle rpm by using the idle air adjustment screw (10).

6 CYLINDER

8 CYLINDER



11.6

**CONNECT** C/O tester after removing the connecting hose (arrow) at the exhaust pick-up tube.



6 CYLINDER




8 CYLINDER



11.7A  
**VEHICLE WITH AIR PUMP: CANCEL AIR INJECTION.**

**DISCONNECT** vacuum line on vertical connection of blue thermo-vacuum valve and plug vacuum valve.




11.7B  
WITH ASPIRATOR (42): DO **NOT** PLUG AIR INJECTION.



**ADJUST FOR PROPER C/O VALUE**

11.8  
**REMOVE** the closing plug and insert the 3mm Allen key through the bore to reach the idle mixture adjusting screw.

TURN TO LEFT = LEANER  
TURN TO RIGHT = RICHER



11.9

**PLUG** the closing plug hole after turning the idle mixture adjusting screw.

**ACCELERATE** engine and recheck the idle C/O value. Readjust if necessary.



11.10

**INSTALL** air filter and recheck idle speed and C/O.

**NOTE:** The C/O will initially go slightly lean when installing a cold air cleaner. C/O should return to the set value after it warms up.

6 CYLINDER

8 CYLINDER



11.11

**RECONNECT** vacuum line to thermo-vacuum valve, or hose to aspirator.




IF CORRECT, proceed to next test as specified in Problem Diagnosis Chart.



IF PROBLEM ACHIEVING CORRECT IDLE SPEED OR C/O, CONTINUE FURTHER TESTING (NEXT PAGE)


## CORRECTING IDLE PROBLEMS

Additional testing to correct rough idle; erratic idle speed; erratic C/O readings; overheating catalyst.



11.12

**MEASURE** idle C/O per procedure for all checks noted.



**A — CHECK CRANKCASE AFFECT:**

11.13

V-8 Engines: **REMOVE** crankcase vent hose and note C/O DROP.

////////////////////////////////////  
IF C/O DROPS more than 1%, the  
crankcase vapors are affecting  
the idle C/O excessively.

////////////////////////////////////

11.13

6 Cyl Engine: **REMOVE** oil fill cap and note C/O INCREASE.

////////////////////////////////////  
IF C/O INCREASES by more than  
1.5%, the crankcase vapors  
are affecting the idle C/O ex-  
cessively.


////////////////////////////////////



IF CORRECT, CONTINUE  
FURTHER TESTING.



**CORRECTION:** EXCESSIVE DROP  
or INCREASE, oil contamination  
or dilution, or excessive blow-by  
are possible causes.



**B — CHECK CHARCOAL CANISTER AFFECT:**

11.14

**REMOVE** Small line going from charcoal canister to engine **BY LOOSENING CLAMP AT CHARCOAL CANISTER.**




**IF C/O DROPS** more than 0.5%, the fuel evaporation control system is affecting the idle C/O excessively.



IF CORRECT, CONTINUE FURTHER TESTING.



**CORRECTION:** Purge valve defective and/or canister saturated with fuel.



**C — CHECK AFFECT OF CYLINDERS NOT PROVIDED WITH MANIFOLD C/O PICKUP:**

11.15

**CHECK C/O** reading at tailpipe.



The C/O reading should not be higher than the reading at the manifold.



**NOTE:** A higher reading at the tailpipe is only of concern if rough idle or an overly hot catalytic is experienced.



IF CORRECT, proceed to next test as specified in Problem Diagnosis Chart.




IF NOT CORRECT: CHECK FOR UNEQUAL FUEL DELIVERY "TEST 13" (PAGE 47)

## TEST 12

# TESTING INJECTION NOZZLES (REMOVED)

**DESCRIPTION** — Characterized by rough idling or engine miss on acceleration.


**PURPOSE** — To test injection nozzles as to opening pressure, possible leaking, and evaluating their spray pattern.



### REMOVE NOZZLES


12.1

**REMOVE** air filter.



12.2


**REMOVE** fuel injection lines. When loosening the injection lines at the fuel nozzles, hold nozzles to keep from turning.



12.3

**REMOVE** hold-down brackets.

**CAUTION:** When removing the hold-down brackets, the nozzles must be held in place in order to avoid pulling out the nozzles and insulating sleeves!



12.4

**PULL OUT** Injection nozzles and make sure to hold down the insulating sleeves.


**NOTE:** If the insulating sleeves are pulled out, they must be reinstalled with new O-rings.

#### TESTING NOTES:

The injection nozzle tester serves to test the opening pressure, the spray pattern, and the nozzles for leaks.

Prior to starting the testing of the injection nozzles, fill the fuel container of the tester with kerosene and bleed the tester.

Any injection nozzle, which is outside the specified tolerances, must be replaced.



12.5

**CONNECT** nozzle to tester.




12.6

**BLEED** pressure line with shut-off valve open and nut of pressure line on injection nozzle loose with slow strokes of the lever.

**NOTE:** DO NOT IMMEDIATELY PUMP THE HAND LEVER VIGOROUSLY.





## B — LEAK TEST

12.B1

**INCREASE** Pressure slowly to 0.5 bar (7 psi) below the previously determined opening pressure of the nozzle and hold this pressure.


**RESULT:** Within 15 seconds no drop should form on the tip of the injection nozzle.



IF CORRECT,  
CONTINUE TESTING



IF NOT CORRECT,  
REPLACE DEFECTIVE NOZZLES



## C — EVALUATION OF NOZZLE SPRAY PATTERN

12.C1

**CLOSE** shut-off valve.



12.C2

**OPERATE** lever at 2 strokes per second then reduce to one stroke per second.

**RESULT:** The nozzle must begin to chatter. The spray pattern should be well atomized. A one-sided but well atomized pattern within a total spray angle of not less than 35° is permissible.




IF CORRECT,  
INSTALL NOZZLES  
(NEXT PAGE)



IF NOT CORRECT,  
REPLACE DEFECTIVE  
NOZZLES






## INSTALLATION

12.7

**INSTALL** injection nozzles. Make sure that the holes on hold-down brackets, (6 cyl) face to the left.

**NOTE:** If the insulating sleeves have been removed, they must be installed with new O-rings.



12.8

**CONNECT** injection lines. 1.0-1.2 kpm (7.5-9 ft. lbs.) torque.

**CAUTION:** When tightening the injection lines, the injection nozzles as well as the connection fittings on the fuel distributor must be held with a wrench to prevent them from turning!

**DO NOT OVER TORQUE LINE FITTINGS!**



12.9

**RUN** engine and check all fuel line connections for leaks.



IF CORRECT, proceed to next test as specified in Problem Diagnosis Chart.




IF LEAKAGE OCCURS, REPAIR OR REPLACE AS NECESSARY

## TEST 13

## TESTING FUEL DISTRIBUTOR


**DESCRIPTION** — Characterized by rough engine idle, overheated catalyst or poor fuel economy,

**PURPOSE** — To check the fuel distributor by measuring the individual fuel quantities which are delivered from the fuel distributor to the injection nozzles.




13.1

**LEVEL** Bosch KDJE-7455 tester using leveling legs and spirit bubble.




13.2

**REMOVE** air filter and unscrew injection lines at fuel distributor.




13.3


**CONNECT** tester fuel lines to fuel distributor in proper sequence.




13.4  
**PLACE** fuel return flow line of tester into fuel tank filler neck.




13.5  
**TURN** selector knob on tester to the left (Learlauf/idle).




13.6  
**OPERATE** fuel pump. **TURN ON** ignition and disconnect fuel pump safety switch to run fuel pump.



13.7  
**DEPRESS** airflow sensor plate and briefly push each tester key one at a time, to bleed the tester.




13.8  
**ATTACH** adjustment fixture for airflow sensor plate to holding bar for rubber stop.



**TEST A**


13.9  
**HOLD DOWN** one tester key while adjusting position of airflow sensor plate with the adjustment fixture to provide an idle flow rate of:

6 cm<sup>3</sup>/minute



13.10

**LOCK** the adjustment fixture and depress the other keys one at a time.



13.11

**READ** the individual flow rates and enter them on the test sheet, (MBNA/MBC 437, see pg. 53).


**RESULT:** The permissible difference between smallest and largest flow rate is 1.2 cm<sup>3</sup>/min.



IF CORRECT, CONTINUE TESTING




IF NOT CORRECT: Replace fuel distributor.



**TEST B**

13.12


**TURN** selector knob on tester to right (Teil-last, Vollast/part load, full load).



13.13


**HOLD DOWN** one tester key while adjusting position of airflow sensor plate with the adjusting fixture to provide a partial load flow rate of:

30cm<sup>3</sup>/minute



13.14

**LOCK** the adjustment fixture and depress the other keys one at a time.



13.15

**READ** the individual flow rates and enter them on the test sheet.


**RESULT:** The permissible difference between smallest and largest flow rate is 6.0cm<sup>3</sup>/min.



IF CORRECT, Continue Testing



IF NOT CORRECT: Replace fuel distributor.




**TEST C**

13.16


**HOLD DOWN** one tester key while adjusting position of airflow sensor plate with the adjusting fixture to provide a full load flow rate of:

100cm<sup>3</sup>/minute



13.17

**LOCK** the adjustment fixture and depress the other keys one at a time.



13.18

**READ** the individual flow rates and enter them on the test sheet.

**RESULT:** The permissible difference between smallest and largest flow rate is 10.0cm<sup>3</sup>/min.



IF CORRECT, End of C.I.S. test sequence



IF NOT CORRECT: Replace fuel distributor.