

At the first and second maintenance jobs,
then every 15 000 km/10 000 miles

All types

Special tool

Radiator tester

001 589 48 21 00

Note

Attention! Check for leaks must only be carried out
with the **engine cold**.

Exchange all porous, hardened or swollen cooling
water hoses.

- Fill radiator in the prescribed manner.
- Place radiator tester (1) in place of radiator cap on
the radiator and lock.
- Then produce a pressure of 1.0 to 1.3 atü in the
cooling system by pumping.
- Check all cooling and heating water pipes and
connections for water loss.
- If necessary retighten hose clamps.

