

Every 15 000 km / 10 000 miles

All engines

- Check for ease of movement and wear on the control shafts, control levers, relay lever, ball sockets and control linkage.
- In the case of the Diesel engine check for ease of movement and full opening of the non-return throttle.

