


All types

Every 15 000 km / 10 000 miles

## Special tool


Piston setting pliers

111 589 07 37 00



30 Cylinder brush

- Remove brake pads (see item 707).
- Clean the brake pad guide in the brake caliper with a cylinder brush.
- Carry out visual inspection for cracks in the dust caps and sealing of the pistons. If a dust cap is damaged, the brake caliper must be removed and repaired.



31 Piston setting pliers

- Press back pistons using piston setting pliers.

## Note

Pistons of the brake caliper **without balancing device** must be pressed back easily. On the other hand, pistons in brake calipers with balancing device are more difficult to press back into their final position, as the friction moment of the guide pin has to be overcome.

	Front axle	Rear axle
with balancing device	100	100 108 109 111 113
without balancing device	107 108 109 111 113 114 115 116	107 114 115 116