

Every Gasoline Engine

Every 15 000 km / 10 000 miles

- On engine M 110 the recesses in the cylinder head must be blown out with compressed air prior to removing the spark plugs.
- Fit spark plugs according to spark plug table.
- Before installing spark plugs check gap of electrodes.

Approximate torque for tightening of spark plug:
25–30 Nm (2.5–3.0 kpm).

Note for vehicles of USA-version:

When using heavily leaded fuels, the spark plugs should be renewed every 5 000 miles.