

Type 100

At the first and second maintenance jobs,
then every 15 000 km / 10 000 miles**Oil type**

Hydraulic oil

BP Aero Hydraulic 1
Castrol DB Hydraulik Fluid
Esso Unavis J-43
Mobil Aero HFA
Shell Aero Fluid 4

Capacity	total (ltr)	1.6–1.8
----------	-------------	---------

- Check oil level in the reservoir **with the engine running.**

- If necessary top up to maximum level with the engine running.

Please note! For this purpose, all hydraulically operated parts such as windows and sliding roof **must be closed** and the seat adjustment must be in the **reclining position**, as otherwise it is possible that the reservoir will overflow during subsequent operation.