Indicator Lamp Symbols

Function Indicator Lamp



High beam

Warning Lamps

(should go out with the engine running unless)




Battery not being charged.
See page 64




Brake fluid low (except Canada).
Parking brake engaged.
See pages 58, 67



Brake fluid low (Canada only).
Parking brake engaged.
See pages 58, 67



Brake pads worn down.
See page 67



Engine oil level low.
See page 64




Coolant level low.
See page 66



Fluid level for windshield and headlamp washer system low.
See page 66




Exterior lamp failure.
See page 65



ABS malfunction.
See page 68



SRS malfunction.
See page 43



ASR malfunction.
See page 69



Engine malfunction.
If the lamp comes on when the engine is running, it indicates a malfunction in the O_2-sensor on Federal version vehicles, and fuel injection system or emission control system on the California version vehicles. In either case, we recommend that you have the malfunction checked as soon as possible.
See page 71