



Lighter

Turn key in steering lock to position 1 or 2.

Push in lighter; it will pop out automatically when hot.

Warning!


Never touch the heating element or sides of lighter, hold at knob only.



Sun Visors

Swing sun visors down to protect against sun glare.

If sunlight enters through a side window, disengage visor from inner mounting and pivot to the side. From this position, the visor can slide forward and backward on its shaft.



Vanity mirror:

With the visor engaged in its inner mounting, the lamp can be switched on by opening the cover.