Removal

- 1 Remove cover molding on lock end (72–130).
- **2** Raise trim strip on edge of side panelling in rear range somewhat.
- 3 Remove rubber frame top at lock end.
- **4** Place plastic wedge under rubber frame at hinge end and knock out clips.
- 5 Remove sealing frame.

Installation

6 For installation proceed vice versa.

Note: always replace clips.