


At the first maintenance job

All types

Tightening torque	Nm	(kpm)
Fixing screws for oil pan with cork gasket	8	(0.8)
Fixing screws for oil pan with rubber gasket	7	(0.7)

- Tighten fixing screws of oil pan with rubber gasket (K 4 C 025, W 4 B 025, K 4 A 040, W 3 A 040 and W 3 B 050) to 7 Nm (0.7 kpm).



- Tighten fixing screws of oil pan with cork gasket (K 4 A 025 and K 4 B 050) to 8 Nm (0.8 kpm).

