

**Important Note**

---

Two rear axle center housings of different size are available for our vehicles with diagonal swing axle. The most distinctive difference is shown by the arrangement of the breather and by the attachment of the two lateral covers.

**Large Center Housing:**

The breather is at the right on rear axle housing. The two lateral covers are each attached with 8 bolts.

**Installation Survey**

---

107	Large center piece
-----	--------------------

---