

# 88.1 Removal and Installation of Air Grille under Bumper

---

107

## Removal

---

- 1 Loosen fog lamp with holding bracket from bumper.
- 2 Remove screws on air grille and remove grille.

## Installation

---

- 3 For installation proceed vice versa.