

Technical Data	Model 107	Job No.	010
General Repair Instructions			
	Jacking-up the Vehicle		210
	Towing the Vehicle		220

