

Fuel Pump 1–14

- 1 Holder
- 2 Nut
- 3 Snap ring
- 4 Anti-vibration buffer
- 5 Washer
- 6 Cheese head screw
- 7 Cheese head screw
- 8 Holder
- 9 Angle connection
- 10 Sealing ring
- 11 Hose clip
- 12 Fuel hose
- 13 Fuel filter
- 14 Fuel pump

Fuel and Compensation Tank 21–45

- 21 Clip nut
- 22 Compensating tank
- 23 Hose clip
- 24 Fuel hose
- 25 Seal
- 26 Immersion tube indicator
- 27 Nut
- 28 Washer
- 29 Rubber sleeve
- 30 Hose clip
- 31 Venting tube
- 32 Rubber
- 33 Filler cap
- 34 Seal
- 35 Rubber sleeve
- 36 Fuel tank
- 37 Sealing ring
- 38 Drain plug with filter
- 39 Suction hose (profilated fuel hose)
- 40 Fuel return flow
- 41 Fuel hose
- 42 Hex bolt
- 43 Snap ring
- 44 Washer
- 45 Reinforcing strip

