

**Attention!**

When working on breakerless transistorized ignition system be sure to observe the following points:

- Persons with heart stimulators should not work on such ignition systems.
- With the engine running or at starting speed, do not touch or pull off components of ignition system, ignition cable, ignition coil, spark plug connector.
- Perform assembly jobs on ignition system only with engine stopped and ignition switched off.

Also connect and disconnect test instruments only with engine stopped and ignition switched off.

- Do not install adaptors or transmitters which are metallically bright on outer side, as for stroboscoping, into ignition cables, e.g. cylinder 1.