gnition System	Job No
Inspection and Adjustment of Timing Angle and Firing Point	510
Replacement of Contact Breaker Points	512
Removal and Installation of Ignition Distributor	530