Cylinder Head and Engine Timing 05.1

M 116, M 117

Cylinder Head	
Removal and Installation of Cylinder Head	Job No
*	119
Replacement of Valve Stem Seals	120
Facing of Cylinder Head Parting Surface	05.0-118
Valve Dimensions	05.0-13
Inspection and Replacement of Valve Guides	05.0-13
Replacement of Valve Seat Rings	05.0-14
Refinishing of Valve Seats	05.0-15
Removal and Installation of Valve Spring	05.0-160
Inspection of Valve Springs	05.0—163
Engine Timing	
Inspection and Adjustment of Valve Clearance	210
Inspection and Correction of Camshaft Timing	215
Removal and Installation of Camshaft	220
Removal and Installation of Rocker Arms	230
Removal and Installation and Inspection of Chain Tensioner	240
Removal and Installation of Tensioning Lever	250
Removal and Installation of Slide Rails	255
Removal and Installation of Intermediate Gear for Distributor Drive	260
Illustration	990