

Oil Filter and Pressure Relief Valves 1–23

- 1 Center screw
- 2 Sealing ring
- 3 Oil filter housing
- 4 O-ring
- 5 Compression spring with spring retainer
- 6 Paper filter element
- 7 Connection
- 8 Intermediate flange
- 9 Gasket
- 10 3 Spring washers
- 11 3 Screws M 8 x 45
- 12 Circlip
- 13 Piston
- 14 Spring
- 15 Pressure relief valve
- 16 Valve ring
- 17 Valve cone
- 18 Spring
- 19 Valve guide
- 20 Overflow valve
- 21 Valve
- 22 Spring
- 23 Locking ring

Air Oil Cooler and Damper Reservoir 30–46

- 30 Air coil cooler
- 31 Lub oil hose top
- 32 Rubber mount
- 33 Lub oil hose bottom
- 34 Drain plug M 12 x 15
- 35 Thread connection
- 36 Sealing ring A 18 x 24
- 37 Damper reservoir
- 38 Elbow
- 39 Diaphragm
- 40 Foam rubber buffer
- 41 Damper cover
- 42 6 Screws M 6 x 20
- 43 6 Spring washers
- 44 Holder
- 45 2 Spring washers
- 46 2 Screws M 6 x 15

Oil Pump 50–63

- 50 Suction strainer
- 51 4 Spring washers
- 52 4 Nuts
- 53 Strainer
- 54 Cover plate
- 55 Circlip
- 56 Oil pump gear wheel
- 57 Drive shaft with oil pump gear wheel
- 58 Oil pump housing
- 59 4 Screws 6 x 30
- 60 Drive gear
- 61 Hollow dowel pin 4 x 6
- 62 Spring washer
- 63 Screw M 8 x 15

