



All types

At the first and second maintenance jobs,
then every 15 000 km / 10 000 miles




Visual inspection:

- Check all parts of fuel system for leakages.
- Check fuel lines and fuel hoses for condition and perfect installation.



- On vehicles with fuel evaporation system, check all parts for leaks.

Check fuel lines and fuel hoses for condition and perfect installation.



- In vehicles with electronically-controlled gasoline injection a special check for leakages and condition of fuel hoses in the engine compartment should be made when the engine is cold.

In doing so switch the ignition on several time for a short period so that there is pressure in the fuel system.

Caution! During 1st and 2nd service, check fuel lines and fuel hoses for firm seat (refer to Job No. 891).