

At the second maintenance job,
then every 15 000 km / 10 000 miles

All types

- Clean rubber abrasion from contact surface of the door weather seal frame using alcohol.
- Rub OREL onto door weather seal frame.