

At the first maintenance job

All types

- Check all hose clamps of the cooling and heating system hoses for a tight fit and retighten.

