

Removal

- 1 Remove side wall in rear of vehicle (68.1–456).
- 2 Remove side window in rear of vehicle (67.1–400).
- 3 On electric window opener, loosen electrical connections on cable connector (1) (Fig. 1).
- 4 Remove reel (2) of safety belt.
- 5 Unscrew three fastening nuts (3) from window opener.

Installation

- 6 For installation proceed vice versa.




Figure 1

- 1 Cable connector
2 Reel

- 3 Nut on window
opener

67.1 Removal and Installation of Shutter

107.02

Removal

- 1 Remove side wall in rear of vehicle (68.1—456).
- 2 Remove window molding strip laterally on roof (68.1—410).
- 3 Remove screws (1) from shutter (2).




Figure 1

- 1 Screws on shutter
- 2 Shutter

Installation

- 4 For installation proceed vice versa.

For sealing, glue a Moltopren strip to shutter starting from below. Apply double Moltopren strip in upper range. Watch out for water leaks during assembly.