

# 88.1 Removal and Installation of Cable Control for Engine Hood

---

107

## Removal

---

- 1** Remove lining under instrument panel.
- 2** Unscrew handle for hood cable control.
- 3** Disconnect hood cable control on handle.
- 4** Disconnect engine hood cable control at front on lower portion of lock.
- 5** Loosen cable strips on engine hood cable control.
- 6** Remove cover plate above windshield wiper motor.
- 7** Pull-out hood cable control with rubber sleeve in engine compartment.

## Installation

---

- 8** For installation proceed vice versa.

Adjust hood cable control free of play on lower portion of lock.