
Removal

- 1** Unscrew both screws on bottom of cover.
- 2** Pull out cover in downward direction.

Installation

- 3** For installation proceed vice versa.

Note: When inserting cover, slide holding springs under clips on instrument panel.