

Removal

- 1** Pull rating plate on center console at upper end slightly forward and push down.
- 2** Pull rating plate on upper end out of center console.

Installation

- 3** Insert rating plate with lower end at front into center console and push downwards.
- 4** Push rating plate at upper end into cutout in center console and push upwards until the rating plate covers the cutout.