




Inspection

1 The stop lamp should light up at a pedal travel between 7 — 20 mm, measured to center of pedal plate.

Adjustment

2 The stop lamp switch is adjusted by means of the two hex. nuts (3), which serve simultaneously to fasten switch (12).