Following each car wash and preservation of engine compartment, lubricate all bearing points of all regulating shafts, regulating levers, joints of regulating linkage and cable controls by means of an oil can.

On **USA version** vehicles only the following hydraulic fluids may be used:

BP Aero-Hydraulik 1 Castrol DB Hydraulik Fluid Esso Univers J-13 Mobil Aero HFA Shell Aero Fluid 4

