


Location of labels
1 Bumper front/rear
2 Engine hood
3 Trunk lid
4 All fenders
5 All doors
Engine*:
on engine block, left rear
Transmission*:
on transmission, left front

*not shown in illustration

Theft Prevention

This vehicle complies with the U.S. Federal Motor Vehicle Theft Prevention Standard (49 CFR Part 541). Engine, transmission and certain body parts (see illustration) are labeled at the factory, the labels show the VIN-number of this vehicle.

Spare parts are similarly labeled at the factory in a different location. The labels show the letter R (for replacement) instead of the VIN-number.

Note:

Do not remove these labels. These labels are intended for parts identification in case of theft. When replacing parts subject to labeling, please make sure that the parts you receive are labeled properly. This is especially important when work is performed outside of the United States.