


P54-0037-B34

Instrument Cluster

1 Knob for instrument lamps and trip odometer.
Rotate knob: To vary intensity of instrument lamps.
Depress knob: To reset trip odometer.

2 Fuel economy gauge. See page 63

3 Coolant temperature gauge. See page 65

4 Fuel gauge with reserve warning lamp (yellow). See page 65

5 Oil pressure gauge (bar). See page 64

6 Turn signal indicator lamp, left (green)

7 Speedometer

8 ASR function indicator lamp (yellow). See page 69.

9 Main odometer

10 Trip odometer

11 Outside temperature indicator. See page 66

12 Turn signal indicator lamp, right (green)

13 Electric clock

14 Tachometer

15 Red marking on tachometer:
Excessive engine speed

16 Knob for clock adjustment
(press in and rotate for adjustments)