#3

MAINTENANCE SERVICE - EVERY 12,500 MILES



All 1975 Models (25 000 Mile Intervals)

Customer:	Work Order No.:				
Address:	License No.:				
City & State:	Mileage:				
Zip Code or Province:	Time Promised:				
Maintenance Work to be Performed:	Special Maintenance Work Performed at Extra Cost:				
 MB Maintenance Service (three sections) with engine oil change and oil filter service. Oil: Brand-Viscosity 	☐ Sliding Roof: Clean guide channels and lubricate lightly.				
Additional Maintenance Work to be Performed	☐ Lighting System: Check headlights and aim. ☐ Battery: Clean housing and terminals; grease				
Every 25 000 Miles:	terminals lightly. Car wash.				
☐ Radiator Coolant:°F FILL/DRAIN/CHECK. Add rust inhibitor.	☐ Wax and Polish.				
 Drain and renew brake fluid, (once a year, preferably in Spring). Use only specified brake fluid. 	☐ Clean Engine and Engine Compartment; lubricate all control linkages.				
M-B Individual Maintenance Jobs Performed as Needed:	Special Instructions from Customer:				
Section I: Lubrication Service Engine oil change with oil filter service. Oil: Brand-Viscosity					
 Section II: Electronic Engine Testing; Engine maintenance. 					
Section III: Safety Inspection.					
Visual Inspection: Check For Leakage and General Cond	ition				
☐ Engine ☐ Rear Axle	☐ Front Axle ☐ Undercarriage				
Steering Brakes	☐ Tires ☐ Body Condition				
☐ Transmission ☐ Shock Absorbers	Exhaust System				
Pasulti					
Result:					
Part I: Service Maintenance with Oil Filter Change					
240D-300D 230	0000				
24 00 2 2 2 3 0 0 0 0 0 0 0 0 0 0 0 0 0 0	240D-300D 230 280-280C 280S 450-All				
151 Engine oil with filter change.	2 2 3 0 2 3 0 0 0 0 0 0 0 0 0 0 0 0 0 0				
Drain engine oil cooler.	O41 Fuel hoses and pipes.				
Inspection for Leaks and Condition	O45 Clutch operating mechanism				
O38 Heating & cooling system.	(240 D only).				

300D							
240b-36 230 280-280 2805 450-All	706 Parking brake: re-adjust.	230 Z Z Z Z Z Z Z Z Z Z Z Z Z Z Z Z Z Z Z	280 - 280 C	098 Road te	est or dynam	nometer	
00000	O28 Maintenance free joints for front axle: check for sealing and condition of steering joint sealing collars. (except 108-109).			(1	Clutch. Manual tran	smission.	
	029 Steering: check for sealing and condition of sealing collars and steering rods.	□□□□□□ 097 Brake test on test stand/road.					
0000	Retightening of Nuts, Bolts, and Retaining Parts 924 Steering gear mounting screws (3).	Tire tread depth and brake performance					
	988 Wheel bolts. 099 Check function of:		Fror	nt – Left	Front – Right		
	—— Headlight, rear lights and stop light.		IN.	КР	IN,	КР	
	— Directional signals: Hazard warning lights.		Rea	r-Left	Rear	Right	
	Windshield wiper, windshield washer.Heating and ventilation.		IN.	KP	in.	KP	
Ma							
	aintenance Additional Ma M	intenance Wo			ed Every	25,000 Miles	
240D-300D 230 280-280C 280 S 450-AII			Service	#3Z Tightening of 871 Intake a	of Nuts and and exhaust		
2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	Oil Change	aintenance S	Service	Tightening of 871 Intake a flange b	of Nuts and and exhaust polts. t pipe flange	Bolts manifold nuts and exhaust	
	Oil Change 170 Automatic transmission oil change. Filter Replacement or Cleaning 174 Automatic transmission: replace filter	element.	280 - 280 C 280 S - 450 - All	#3Z Tightening of 871 Intake a flange be Exhaus: 876 Carburd	of Nuts and and exhaust polts. t pipe flange etor mountin	Bolts manifold nuts and exhaust e only. ng flange screws	
	Oil Change 170 Automatic transmission oil change. Filter Replacement or Cleaning 174 Automatic transmission: replace filter 612 Power steering: Replace filter element	element.	280 - 2800 280 2 800 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	#3Z Tightening of 871 Intake a flange be Exhaus 876 Carburd Checking 501 Check of transmid 625 Check for 1985	of Nuts and and exhaust polts. It pipe flange etor mounting clutch lining ission only).	Bolts manifold nuts and exhaust conly. ng flange screws thickness (manual (240 D only). toe-in.	
	Oil Change 170 Automatic transmission oil change. Filter Replacement or Cleaning 174 Automatic transmission: replace filter 612 Power steering: Replace filter element 840/847 Fuel filter: Clean element or replace 845 Fuel main filter: Clean filter element and filter housing	element.	280 - 2800 280 2 800 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	#3Z Tightening of 871 Intake a flange is Exhaus 876 Carburd Checking 501 Check of transmid 625 Check from 625	of Nuts and and exhaust polts. It pipe flange eter mounting sion only).	Bolts manifold nuts and exhaust e only. ng flange screws thickness (manual (240 D only).	
	Oil Change 170 Automatic transmission oil change. Filter Replacement or Cleaning 174 Automatic transmission: replace filter 612 Power steering: Replace filter element 840/847 Fuel filter: Clean element or replace 845 Fuel main filter: Clean filter element and filter housing 844 Fuel pre-filter: check	element.	280 - 2800 280 2 800 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	#3Z Tightening of 871 Intake a flange be Exhaus: 876 Carburd Checking 501 Check of transmit 625 Check from 6	of Nuts and and exhaust polts. It pipe flange etor mounting ssion only). It ront wheel to propeller shape.	Bolts manifold nuts and exhaust conly. ng flange screws thickness (manual (240 D only).	

Service Manager (Signature) ___

Date _