


Every 15 000 km / 10 000 miles

All engines

**Condition**

Check V-belts for cracks, aging, wear and tension.

**Tension**

The V-belt is correctly tensioned when the prescribed deflection is not exceeded (Job no. 756).

Deflection is measured with a perpendicular pressure of 6 kp on the longest belt side.