


Engines **M 110 114 116 117**

At the first and second maintenance jobs



- Check all hose clips on the fuel pipes and hoses from the fuel pump to the pressure regulator (fuel pressure side) for tight fit. **Especially the fuel hoses in the distributor line in the engine compartment.**

Note: In the case of hose clips they are still not definitely leakproof although they are tightened to their end, either the fuel hose, the hose clip or the resp. injection valve has to be replaced.

M 116, 117