


All types

Every 15 000 km / 10 000 miles



- Check brake discs for scouring and cracks. Scouring in circumferential direction up to 0.5 mm deep is permissible.
- Badly contaminated brake discs, characterised by grey or blue discolouration of the brake surface, must be cleaned using a cleaning pad.