


Types 107 114 115 116


At the first maintenance job

Tightening torque, kpm	Nm	(kpm)
Hex. socket screws M 8 x 20	25	(2.5)



Type 107, 116  
5 Rubber mounting

- Check tightness of four hex. socket screws attaching the rear rubber mounting to the frame floor.



Types 114, 115